




D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
 PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
 RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
 SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



1/1

Nano - Nano - Nano - Nano - Nano - Nano - Nano - Nano - Nano - Nano


HYACINTH




3DL URC



URC 3DL



US 5x35
x 2 A1



UP 5x35
x 20 A2




WS M6x40
x 2 A3



WS M6x20
x 24 A4




WP M6x50
x 3 A5




x 3 A6



x 12 A7




x 2




TW
L 230
x 6 E







TW
H 25
x 8 E1



x 2 B




x 1 B1




Service-Dienstverlening-Serwis-Servis-Сервисная служба-Assistenza-Szerviz

Typ-1yp-1p-1m-1pa-1po

A
B
C
D
E
F
G



3DL.URC



3DL.URC

7

URC.3DL

7

