





MONTAGEANLEITUNG / MONTÁŽNÝ NÁVOD // SERVISKARTE / SERVISNÁ KARTA







CHALET TYPE/TYP 74





H 355mm
H-I 389mm






1	 $\varnothing 8 \times 35$ x40	2	 $\varnothing 8$ x20
3	 $\varnothing 15$ x20	4	 $\varnothing 3,5 \times 15$ x8
5	 x4	6	 x4
7	 x9	8	 $\varnothing 3,5 \times 20$ x28
9	 $\varnothing 6,3 \times 11$ x8	11	 x4
10	 $\varnothing 15$ x19		
12	 $\varnothing 5$ x20	13	 x1
		14	 $\varnothing 15$ x12
		15	 M4x10 x4
		16	 $\varnothing 5/2 \times 16$ x8
		17	 x4
		18	 $\varnothing 1.2 \times 25$ x8









18



20



19



21

