



Model: Montona skrinka



Komponenty









Č. komp.	Dĺžka	Šírka	Množstvo	Detailné číslo
1/1	1250	382	2	1
	448	382	2	2
	1248	90	1	3
	1248	90	1	4
	1248	302	1	5
	448	356	2	6
	1234	464	1	7
Komponenty				



Všeobecný prehľad komponentov

A - 16	B - 8	B1 - 8	C - 24	D1 - 16	D2 - 8	I - 1
S1 - 6	S2 - 14	S3 - 4	SW - 4	W - 4	CD - 2	CH - 1
HF - 3	SH - 6	T - 8	R - 14	M - 3		


Model: Montona skrinka



1

							
A - 16	B - 8	B1 - 8	C - 24	HF - 3	S1 - 6	CD - 2	S3 - 4



2




D1 - 8



Model: Montona skrinka




3

D1 - 8 D2 - 8





4

T - 8 SH - 6






5

M - 3



6

R - 14 3,5x20
S2 - 14



Model: Montona skrinka

7

